

# PODEŠAVANJE RUTERA Air Live 5460AP V2 NA DYNAMIC DHCP

U adres bar-u vašeg internet pretraživača ukucajte pristupnu IP adresu (192.168.100.252) rutera (1). Na Welcome stranici izaberite **Mode** (2). Čekirajte opciju **Gateway** i kliknite na **Setup** (3). Na novoj stranici kliknite **Setup** za **Wan Port** (4). U padajućem meniju **WAN Access Type** odaberite opciju **DHCP Client** (5), a zatim potvrdite podešavanja sa klikom na **Save** (6). Nakon toga će te dobiti upozoravajuću karticu koju potvrđujete na **OK** (7). Da bi sve promjene na rutru bile primjenjene potrebno ga je restartovati tako što će te iz glavnog menija izabrati opciju **Reboot** (8) i kliknuti na dugme **Reboot** (9).

The following steps are illustrated in the screenshots:

- Enter the IP address 192.168.100.252 in the browser address bar.
- Click on the **Mode** tab in the main menu.
- Select **Gateway** under the **Wireless Mode** section and click **Setup**.
- Click **Setup** for **Wan Port** in the **WAN Port Configuration** section.
- Select **DHCP Client** from the **WAN Access Type** dropdown menu.
- Click the **Save** button to confirm the settings.
- Click **OK** on the warning message box.
- Click on the **Reboot** tab in the main menu.
- Click the **Reboot** button in the **Reboot System** section.